
# How to set the chromaticity at transition

Christoph Montag

RHIC Retreat, July 10-13, 2006

- Chromaticity has to change sign around transition.
- Zero chromaticity at transition, when bunches are very short, causes fast transverse instability.
- Crossing zero just before transition, plus application of octupoles, avoids instability.
- $\gamma_t$  jump causes  $\approx +2$  units chromaticity jump. If chromaticity is still negative before the jump, it may jump right onto zero at transition.
- At the beginning of ramp development in each run, chromaticities are set to -2 before and +2 after transition – and then they get adjusted.

#### Chromaticity setpoints across transition, FY04 and FY05




Chromaticity setpoints change 5-10 units across transition; typical change: 8 units

Chromaticity change (setpoints) is twice as high as expected!

## Measurement by Steve Tepikian:






Chromaticity increments are factor 2 off!

#### Recipe


- Start with chromaticity change (setpoints) of 8 units (instead of 4) across transition
- When adjusting chromaticity around transition, keep this increment constant.
- Decoupling at transition is important, since skew chromaticity may be zero.

This results in a one-parameter adjustment, namely the actual chromaticity around transition — and therefore the zero-crossing time:




## Diagnostics

• Chromaticity measurement along the ramp



# • Phase space tomography



• Coherence monitor